

VELVET FROZEN

USER INSTRUCTIONS

N° DOC. UM000346
REV. "-" - 17.12.18

TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	2/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

INDEX

CAP. N°		N° PAG.
/	INDEX.....	pag.2
/	SAFETY ADVICE.....	pag.3
1	INTRODUCTION.....	pag.4
2	CE MARKING.....	pag.5
3	RESPONSABILITY, VALIDITY AND COPYRIGHT.....	pag.7
4	INTENDED USE.....	pag.8
5	HANDLING AND STORAGE.....	pag.9
6	AMBIENT CONDITIONS FOR INSTALLATION.....	pag.11
7	INSTALLATION.....	pag.12
8	FIRST START-UP.....	pag.13
9	USE OF THE CABINET.....	pag.14
10	CLEANING.....	pag.16
11-12	MAINTENANCE; DISPOSAL.....	pag.19

TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	3/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

SAFETY ADVICE

ENSURE THAT AIR SLOTS ON THE CABINET ENCLOSURE ARE FREE FROM OBSTRUCTION.

DO NOT USE SCRAPE FROST OFF USING TOOLS OTHER THAN THOSE RECOMMENDED BY THE MANUFACTURER.

DO NOT USE ANY ELECTRICAL APPLIANCES INSIDE THE STORAGE COMPARTMENTS FOR THE FOOD FROZEN BY THE EQUIPMENT, UNLESS RECOMMENDED BY THE MANUFACTURER.

DO NOT STORE EXPLOSIVE SUBSTANCES SUCH AS PRESSURIZED FLAMMABLE PROPELLANT CONTAINERS IN THE REFRIGERATED CABINET.

KEEPING PHARMACEUTICALS, GLASS BOTTLES OR FLASKS IN THE CABINET IS STRICTLY FORBIDDEN AS THEY COULD GET BROKEN AND ENTAIL A SAFETY HAZARD.

ONLY QUALIFIED PERSONNEL CAN REMOVE PANELS OR GUARDS, AND ESPECIALLY THE ELECTRIC BOARD COVER, WHEN THIS REQUIRES THE USE OF TOOLS.

DO NOT EXPOSE THE EQUIPMENT TO ATMOSPHERIC AGENTS.

DO NOT USE DIRECT OR INDIRECT WATER JETS ON THE CABINET. DO NOT TOUCH THE EQUIPMENT WITH DAMP OR WET HANDS OR FEET; DO NOT USE IT WHILE BAREFOOT.

THE EQUIPMENT IS NOT AIMED TO BE USED BY PERSONS HAVING IMPAIRED PHYSICAL, SENSORIAL OR MENTAL FACULTIES (CHILDREN INCLUDED), OR BY PERSONS HAVING POOR EXPERIENCE OR KNOWLEDGE, UNLESS THEY ARE SUPPORTED BY SOMEBODY IN CHARGE OF THEIR SAFETY OR BY THE INSTRUCTIONS FOR THE USE OF THE EQUIPMENT. SURVEILLANCE MUST BE EXERCISED ON CHILDREN IN ORDER FOR THEM NOT TO PLAY WITH THE EQUIPMENT.

THE POWER CORDS MUST BE PROPERLY SPREAD OUT, SAFE FROM SHOCKS AND FAR FROM LIQUIDS, WATER AND HEAT SOURCES, AND IN PERFECT CONDITION. THE USE OF ADAPTOR PLUGS IS FORBIDDEN.

ENSURE THAT THE POWER SUPPLY VOLTAGE MEETS THE DETAILS ON THE RATING PLATE OF THE CABINET. THE CABINET MUST BE PROPERLY CONNECTED TO THE EARTHING SYSTEM.

JOBS INVOLVING THE COOLING CYCLE OR THE WIRING SYSTEM MAY ONLY BE PERFORMED BY QUALIFIED PERSONNEL. DISCONNECT THE CABINET'S PLUG FROM THE MAINS OUTLET BEFORE ANY JOBS.

RNAL WALLS OF THE EQUIPMENT AS THIS COULS COMPROMISE CABINET PERFORMANCE.

IN ORDER TO REDUCE FLAMMABILITY-RELATED RISKS, THIS CABINET MAY ONLY BE INSTALLED BY SUITABLY QUALIFIED PERSONNEL.

UNDER UNFAVORABLE CONDITIONS, LIGHTNING STRIKES ON THE SUPPLY NETWORK OR NEAR THE INSTALLATION, MAY CAUSE THE LAMPS TO GO OFF AND REQUIRE SERVICING

ANY OTHER USE NOT EXPLICITLY MENTIONED IN THIS BOOKLET MUST BE CONSIDERED AS HAZARDOUS. THE MANUFACTURER DISCLAIMS ALL LIABILITY FOR DAMAGE RESULTING FROM IMPROPER, INCORRECT OR UNREASONABLE USE.

TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	4/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

1. INTRODUCTION

1.1 CLAUSES

THIS INSTRUCTION MANUAL IS AN INTEGRAL PART OF THE PRODUCT AND MUST BE KEPT UNTIL THE PRODUCT IS DISMANTLED.

THE MANUAL MUST BE KEPT BY A PERSON RESPONSIBLE FOR IT, IN A PLACE THAT IS SUITABLE AND KNOWN TO ALL INDIVIDUALS CONCERNED, SO THAT IT IS ALWAYS AVAILABLE FOR CONSULTATION.

1.2 CONTENT OF THE MANUAL

This manual contains information on the installation, use and maintenance of the product. It also contains information on the technical features and safe use of the product.

1.3 PURPOSE OF THE MANUAL AND INDIVIDUALS INVOLVED


The information contained in the instruction manual indicates the use of the product and its technical features in addition to directions regarding its handling, installation, assembly, adjustment and use. It also contains information on the instructions to give to the operators put in charge of its use, as regards maintenance work, and to protect their safety.

This instruction manual has been written for the:

OPERATOR: qualified person, in charge of the operation, adjustment, cleaning and routine maintenance of the display cabinet.


SPECIALIST TECHNICIAN: person in possession of the technical training and experience necessary to make him aware of the risks he is exposed to in carrying out work and make him capable of adopting the necessary measures to cause the least harm to self and others. He is authorized to carry out extraordinary maintenance repairs, replacements and overhauling.

The title of every section specifies the person the chapter caters for (OPERATOR or SPECIALIST TECHNICIAN). If there is no specification the chapter refers to both people listed above.



TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	5/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

1.4 MANUAL LAYOUT AND LEGEND



IMPORTANT; This symbol is used to signal advice, rules, cross-references and communications which any person involved in the use of the product (each according to his responsibility) must bear in mind during all stages of the product life (installation, use, maintenance, dismantling, etc.).



CAUTION; This symbol is used in the safety messages of the manual to signal hazards which, if disregarded, could cause small or moderate injuries or damage. The message can also be used to signal the conditions which can damage the product.



HAZARD; This symbol is used in the safety messages of the manual, to indicate behaviour which must be avoided at all costs during use of the equipment, maintenance work or when there are potentially hazardous situations and the probability of causing serious injuries or death.

TO AVOID ACCIDENTS, read, understand and observe all the precautions and warnings contained in this manual and those shown on the labels applied to the product.

2. CE MARKING

This product is accompanied by documentation that certifies its conformity with the directive in force and which shows its essential features.

In particular, it provides:

1. Product details (serial number, date, product code)
2. Name of manufacturer
3. Electrical rating (Voltage, frequency, amperage, wattage)
4. Power – amperage when defrosting (if defrosting is electric)
5. Power of auxiliary heating systems.
6. Lamp wattage
7. Refrigerant fluid number and mass
8. Climate class, temperature and relative humidity of the reference climate class.
9. Insulation blowing gas
10. CE marking and any other marks

The plate must remain unchanged over time; it shows the details to provide to COSTAN if the need for assistance arises.

TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	6/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

1

2 → Manufactured by Euro'Cryor S.p.A. - Solesino 35047 MADE IN ITALY

3 → RATED BEMESSUNG ASSIGNÉ NOMINALE NOMINAL **230V~** **W**
50Hz **A**

4 → DEFROSTING ABTAUUNG DÉGIVRAGE SBRINAMENTO DESCONGELAMIENTO

5 → HEATING SYSTEM HEIZUNGSSYSTEME SYSTEMES CHAUFFANTS SISTEMI DI RISCALDAMENTO SISTEMA DE CALEFACCION

6 →  **W**



SN EC0000 17/11/10
REF XXXX YYY

REFRIGERANT KÄLTEMITTEL REFRIGÉRANT REFRIGERANTE REFRIGERANTE **7** → **Kg**

CLIMATE CLASS KLIMAKLASSE CLASSE CLIMATIQUE CLASSE CLIMATICA CLASE CLIMÁTICA **8** → **3 - 25°C/60% R.H.**

INSULATION BLOWING GAS ISOLATIONSGAS (BLÄHGAS) AGENT MOUSSANT D' ISOLATION GAS ESPANDENTE ISOLAMENTO AGENTE ESPUMANTE **9** → **CO2**

PROTECTION INDEX SCHUTZART INDEX DE LA PROTECTION INDICE DI PROTEZIONE INDICE DE PROTECCION **10** → 

 Read Operator's Manual available at www.eptarefrigeration.com or calling +39 0437 968379

**The A weighted sound pressure level emitted by the meuble is less than 70dB (A).
The cabinet does not generate any harmful vibration.**

TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	7/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

3. RESPONSABILITY

THE INSTRUCTON MANUAL IS AN INTEGRAL PART OF THE PRODUCT AND MUST BE KEPT UNTIL THE END OF ITS LIFE.

The manufacturer declines any responsibility deriving from:

- improper, incorrect or unreasonable use of the product.
- use which is contrary to the national regulations in force.
- incorrect installation of the product.
- incorrect power supply.
- poor maintenance.
- unauthorized modifications or interventions.
- use of spare parts and products which are not original or not specific for the model.
- failure to observe the instructions contained in this manual.

3. VALIDITY AND COPYRIGHT

3.1 GENERAL INFORMATION

This use and maintenance manual, including all the attachments, is the only documentation provided with the equipment and accompanies it for the entire time of its operation. If lost or damaged, the replacement documentation must be requested directly from COSTAN.

3.2 VALIDITY OF THE MANUAL

This manual reflects the technical status and technology used to construct the equipment, valid at the moment in which it is marketed; it cannot be considered inadequate or obsolete if it is subsequently updated according to new experiences.

3.3 RIGHT OVER THE MANUAL

COSTAN reserves the right to update its production and, consequently, the applicable use and maintenance manual. It is under no obligation to advise the Customer of the modifications made.

3.4 COPYRIGHT

This manual is the exclusive property of COSTAN. Handing this manual over to third parties must be authorized by COSTAN's management team. It is strictly prohibited to copy, reproduce with any medium, even partially, drawings and documents contained in this manual. Any violation will be prosecuted according to the law and entitles to compensation for damages according to trade regulations provisions.


TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	8/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

4. INTENDED USE (OPERATOR)

The product is intended to be used by qualified staff, i.e. staff who has been instructed and trained by the employer to use the product and on the risks which its use can cause.

Read the manual attentively before use and instruct the operator to use the equipment according to the instructions set out in the manual.

The content of the manual is also valid for all staff in charge of transport, installation, maintenance and dismantling of the product, each according to their responsibility.




The product must be used exclusively for the purpose it was designed for, as indicated in the manual.

The Cabinet is suited exclusively to displaying frozen food.

The Cabinet is NOT suitable for lowering the temperature of the product but only for maintaining it.

The goods introduced in the cabinet MUST already be at their preservation temperature.

It is absolutely forbidden to display pharmaceuticals.



During normal use of the cabinet the front glazing must remain closed; it can only be fully opened during maintenance or cleaning activities. Intermediate positions are prohibited.

It is prohibited to remove any guard or panel if a tool is required to do so.

It is forbidden to tamper with or alter the product.





Any other use which is not specifically indicated in the manual is considered hazardous and COSTAN cannot be held responsible for any damage caused by improper and unreasonable use.

TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	9/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

5. HANDLING AND STORAGE (SPECIALIST TECHNICIAN)

5.1 HANDLING

The loading and unloading operations must be performed by qualified staff, who will verify the exact weights and lifting points; they will use lifting equipment which is safe and with a suitable carrying capacity. There must be no individuals who are not involved in the operation close to the lifting points.



The package must be lifted by inserting the forks of the lift truck into the space between the legs of the pallet or crate. The weight of the equipment must be divided so that the centre of gravity of the package remains balanced (Fig.1-A). Do not tip the equipment over.




Before inserting the forks of the lift truck, verify that these cover the entire depth of the package (Fig. 1-B). If not, install appropriate extensions.

PROHIBITED LIFTING MEANS

Lifting means or equipment which do not respond to the safety requirements must not be used. These include:

- lifting capacity lower than the weight of the equipment;
- unsuitable construction features of the forklift truck (e.g. short forks);
- construction features altered by use;
- non-compliant ropes or cables;
- worn-out ropes or cables.

Any other handling procedure different to those described in this chapter are prohibited.



TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	10/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				



DON'T PUSH THE CABINET THROUGH THE UPRIGHTS

5.2 STORAGE

The equipment must be stored in a dry humidity-free environment. It must be covered with a sheet before storage to protect it from dust or dirt.



The maximum storage temperature is 55°C.

TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	11/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

6. AMBIENT CONDITIONS FOR INSTALLATION



**The equipment must be installed in a closed environment, covered and safe from atmospheric agents.
The equipment must not be installed in areas containing explosive substances.**




Fig. 2

Position the equipment far from draughts (fan-coil, fans, windows, air outlets).

Avoid exposing the equipment to direct sunlight, to concentrated light units or to sources of heat such as radiators, stoves or ovens.

Ensure there is sufficient air circulation on all sides of the cabinet.

It is absolutely forbidden to position objects around the counter which can in some way hinder the circulation of air over the condensing unit.

Failure to comply with the above requirements can, in addition to the fast deterioration of the materials composing the cabinet, cause poor

operation of the cabinet, including:

- Higher energy consumption.
- Mist formation on the cold surfaces (glazing or countertop).
- Poor preservation of the foods of the counter and the risk of making the displayed goods deteriorate.

The ambient temperature must fall within the temperature limits established by the class of equipment (25 °C - 60% of humidity). If these limits are exceeded the performance of the equipment will be lower.

TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	12/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

7. INSTALLATION (SPECIALIST TECHNICIAN)

INCORRECT INSTALLATION OF THE PRODUCT MAY CAUSE HARM TO PEOPLE OR DAMAGE TO PROPERTY. THE MANUFACTURER CANNOT BE HELD RESPONSIBLE FOR THE ABOVE HARM OR DAMAGE.



Any variation or modification to the installation conditions must be authorized in advance by Epta. The operations described in this chapter must be performed by qualified staff.

To guarantee that the people in charge of installing the product can work in safe conditions, we strongly recommend attentively following the installation procedure described here. In any case, it is advisable to use suitable equipment or clothing: **safety shoes, protective gloves, spirit level.**


We also recommend using all the tools or protection equipment required by the regulation, or by the laws in force of the country where it is installed.

ELECTRICAL CONNECTIONS



The operations described in this chapter have been carried out by specialized personnel.

The systems must comply with the regulations that govern their construction, installation, use and maintenance. COSTAN declines any responsibility towards users and third parties for any damage that may be caused by malfunction or faults in the systems that power the product. It also declines any responsibility for damage which could be caused by the product by causes that are directly dependent on the malfunction of the electrical system.



THIS EQUIPMENT IS CLASS I: CONNECTION TO A GROUNDING SYSTEM IS MANDATORY. The manufacturer disclaims responsibility when this prescription is not complied with.

Upstream of the power socket install a thermal-magnetic circuit breaker in overvoltage category III, with capacity suitable for the power/current values defined in the technical data table.

Instruct the operator on the position of the switch so that it can be reached quickly in an emergency.

The customer is responsible for arranging a power supply line to the equipments connection point.

The size of the power supply line must be chosen according to the power absorbed by the equipment (see technical features table).

Verify that the power supply voltage and frequency reflect the values defined in the label or that they differentiate at the most by 5% the first and by 2% the second.

TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	13/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

You are reminded that:

- It is obligatory to consult the wiring diagrams before making the connection.
- To comply with the abbreviations on the terminal block.
- To connect the protective conductor to the earthing terminal.
- The maximum section allowed for the power supply conductor is 4 mm²
- End sleeves can be used. Do not solder the conductors.
- Having secured the conductor to the terminal try to pull it to check if it has been secured correctly.

8. FIRST START-UP (OPERATOR)

8.1 FIRST CLEANING

Wear protective gloves to carry out the activities described in this chapter.



Clean the cabinet thoroughly before starting it up.
The instructions are specified in the "CLEANING" chapter.

8.2 START-UP




Switch ON the selector.
The cabinet starts the cooling cycle.

TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	14/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

9. USE OF THE CABINET (OPERATOR)

9.1 PERFORMANCE

The Cabinet is suited exclusively to displaying frozen food. The Cabinet is NOT suitable for lowering the temperature of the product but only for maintaining it. The goods introduced in the cabinet MUST already be at their preservation temperature. It is absolutely forbidden to display pharmaceuticals.




9.2 LOADING THE PRODUCT

Before placing the goods inside, check the DISPLAY SHELVES are positioned correctly.

The goods must be placed inside the cabinet only when the set temperature has been reached.

Caution: do not lay the goods directly on the painted display shelf if it is present.




Check the consistency of the packaging before displaying packaged products containing liquids whose leakage could damage the cabinet. Otherwise, place the packaged product into a container.




When loading the products and as long as they are inside the cabinet, pay maximum attention to respecting the maximum load limit defined by the labels on the side (see image below).

TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	15/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				



- Don't obstruct "B" slot of refrigerated air exit.
- Don't obstruct "C" slot of air intake.
- Don't obstruct refrigerated air flow; leave spaces between product.
- Don't exceed the admitted load for the display shelves (see technical sheet)



Per un corretto funzionamento dell'espositore oltre che per un minore consumo energetico, le porte scorrevoli devono restare aperte il minor tempo possibile.

Nel caso in cui le porte scorrevoli rimangano chiuse per un tempo prolungato, è possibile che si formi della condensa anche nella parte superiore del mobile.

Per ridurre questo effetto si consiglia di aprire le porte scorrevoli per fare fuoriuscire un po' di aria fredda e quindi richiuderle.

Per un corretto funzionamento dell'espositore si consiglia di fare sbrinare COMPLETAMENTE l'espositore una volta alla settimana.



To facilitate loading/unloading the goods we recommend opening the front glass.
Do not obstruct air exit and entrance points.

TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	16/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

9.4 ACCESSORIES

9.4.1 FRONT ANTI-MIST


The cabinets avail of an anti-condensation ventilation system for the front glass. If the excess humidity of the environment were to create problems like misting of the crystals, a warning light switch assembled on the control panel at the back of the cabinet, see figure below, allows to turn on an anti-mist heating element.

The heating element turns off automatically after an hour of operation (warning light switch off); if the need to use it persists, press the button again.

The time of operation of the heating element may be varied; in this case, contact your closest assistance centre who will make the change.

9.4.2 ILLUMINAZIONE

The Lighting is activated/deactivated by the switches positioned on the panel (fig. below)



10. CLEANING



Before starting any cleaning operation switch off the power.



Wear protective gloves to carry out the activities described in this chapter.



It is totally forbidden to use water jets to clean the equipment.

TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	17/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

10.1 ESTERNAL CLEANING

Clean all the external parts of the cabinet on a weekly basis, using exclusively warm water and soap or neutral detergent for domestic use diluted in water. Dry carefully using a soft cloth. **It is forbidden to use flammable or abrasive products such as alcohol, acetone or solvents; Do not use detergents that contain non-ionic surfactants, lemon, or vinegar (acetic acid).**

NEVER USE JETS OF WATER TO CLEAN THE CABINET. Use only glass cleaning products to clean glass surfaces. It is not recommended to use water because it can leave scale deposit on the glass surface.

CLEANING FRONT GLASS



To facilitate the cleaning operations of the front glass, it is always recommended to open it (lift it upwards, pull it outwards or to the side, depending on the model of the superstructure). Be careful not to make force on the upper glass.

10.2 INTERNAL CLEANING



Clean all the internal parts of the cabinet on a monthly basis, following the same indications set out at the preceding point and **using exclusively a non-abrasive sponge. The maximum water temperature used for cleaning is 65°C.**

To clean the internal parts it is also necessary to follow the instructions below:


- De-energise the cabinet using the main disconnect switch on the wall.
- Empty the equipment completely putting the goods into other refrigerators.
- Wait for the equipment to be at ambient temperature.
- Extract the REMOVABLE DRAWER.



TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	18/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				



Remove the EVAPORATOR-COVER "A"



Attenzione a non tagliarsi con le sottili alette dell'evaporatore o con bordi o spigoli di lamiere adiacenti. Indossare dispositivi di protezione adatti allo scopo.

- Cleaning; per pulire la zona sotto l'evaporatore, si consiglia di versare lentamente e facendo attenzione a non schizzare sui componenti circostanti, dell'acqua calda utilizzando un recipiente adeguato. L'acqua deve essere versata dal lato dello schienale in modo che, defluendo, scorra verso i fori di drenaggio della vasca. Se necessario ripetere l'operazione più volte.
- Per facilitare queste operazioni e la raccolta dell'acqua di lavaggio, è stato previsto uno scarico che convoglia l'acqua usata per la pulizia interna direttamente all'esterno del mobile.
- Dopo aver controllato attentamente che l'interno del banco sia completamente asciutto, rimettere in funzione l'apparecchio ridando tensione al banco.
- Dopo circa un paio d'ore caricare nuovamente il prodotto.

TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	19/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

11. MAINTENANCE (SPECIALIST TECHNICIAN)




The activities described in this chapter must be performed by a specialist technician.



**Any maintenance work must be carried out while the equipment is disconnected from the power source.
Turn off power at the main switch on the wall.
Attention: before accessing the terminals, all the power circuits must be disconnected.**

It is recommended to have a specialist technician perform an annual general check-up of the equipment (gas springs, refrigerator circuit...).




11.1 REPLACEMENT OF LED MODULES

Caution: to replace a LED lighting fixture it is obligatory to contact the cabinet dealer. Do not install alternative components.

11.2 WORK ON PROTECTION SWITCHES

To reactivate the protection switches, access the component chamber (see chapter "electrical connections") and turn the switch to ON.

Attention: before turning on again the switches remove the cause of the fault



Any other maintenance work which is not handled in the previous points must be carried out by service centres authorized by our dealers or by qualified staff.

12. DISPOSAL (SPECIALIST TECHNICIAN)

All countries have different legislations; therefore, the specific prescriptions enforced by the legislation and local authorities of the country where the equipment is demolished must be observed.

A general rule is to hand over the equipment to specialized collection/demolition centres. Disassemble the equipment and divide the components separately according to their chemical characteristics.

The equipment components are categorized as urban waste. Disassembly operations must be performed by qualified staff.


The materials used to construct the cabinet are:

- Iron tube: transport bars.
- aluminium tube: frame.
- galvanized sheet metal: closing panels.
- stainless steel: internal parts of the cabinet.
- polyurethane foam (thermal insulation)

TECHNICAL DOCUMENTATION		STATE REVISION OF THE CHAPTER				IN CONFORMITY WITH THE APPROVED ORIGINAL		
PRODUCT	VELVET FROZEN	ORD.	DATE	ORD.	DATE		PAGE	20/21
N° DOC.	UM000346	A		D			FIRST ISSUE	17.12.18
N° CHAP.		B		E			ISSUE	MKTG
		C		F				

- copper: fridge circuit.
- PVC: various plastic materials.
- tempered glass: front glass.

The components of the refrigeration circuit must not be cut and/or separated, but transferred whole to specialist centres for the recycling of refrigerant gas.




NOTICE

This equipment is subject to the obligations declared in Leg. Dec. 151 of 25 July 2005, Implementation of Directives 2002/95/CE, 2002/96/CE and 2003/108/CE, relating to the reduction in the use of hazardous substances in electrical and electronic equipment, as well as the disposal of waste "only if at the moment of purchase it is equipped with an incorporated Condensing Unit.

Upon the purchase of a new product, the manufacturer is obliged to dispose of an equivalent product (the equipment is equivalent when the weight of the equipment that has been withdrawn is not more than double the weight of the equipment handed over). The rates for any additional components to dispose of or excess in the weight of non-equivalent equipment will be agreed each time.

Pursuant to art.13 of the aforementioned decree, the symbol of the crossed-out wheeled bin on the equipment or on the package indicates that at the end of its useful life the product must be collected separately from other waste.

The separate collection of the equipment (if subjected to the obligations of the directive) which has reached the end of its life is organized and managed by the manufacturer. The user who wants to dispose of this equipment is required to contact COSTAN on 0429-707311 and follow the system that the company has put in place to allow the separate collection of the equipment which has reached the end of its life.



Adequate separate collection so that the disused equipment can subsequently be recycled, treated and disposed of in a way that is environmentally-friendly contributes to avoiding possible adverse effects on the environment and on health and encourages the reuse and/or recycling of the materials which the equipment is made of.

Abusive disposal of the product by the holder will result in the application of administrative penalties as provided for by the legislation in force.

The information on materials used for the production of the equipment can be requested from COSTAN.

Rohs Declaration

The undersigned COSTAN with registered office in Solesino Viale delle Industrie n , Padova, Italy declares under its full responsibility that the object of this manual, namely the refrigerated cabinet equipped with incorporated refrigeration unit, satisfies the requirements of directive 2002/95/CE (RoHS). Any presence of lead, mercury, cadmium, hexavalent chromium, biphenyl, polybrominated biphenyls (PBB) and polybrominated diphenyl ether (PBDE) in the materials used to manufacture the equipment does not reach a weight of 0.1%; the content of cadmium does not reach a weight of 0.01%.



www.costan.com



Epta S.p.A. participates in the ECC programme for:
Refrigerated display cabinets (RDC); Check ongoing validity
of certificate online: www.eurovent-certification.com
or using: www.certifish.com



www.eptarefrigeration.com